

Your Global Automation Partner

TURCK

GEN... Firmware Update via PACTware

Technical Support Document



1 About these instructions

These instructions describe the process for updating the firmware of the GEN... Ethernet gateway via PACTware.

1.1 Target groups

These instructions are intended for qualified personnel and must be read carefully by anyone operating and maintaining the device.

When using the device in Ex circuits, the user must also have an additional knowledge of explosion protection (IEC/EN 60079-14 etc.).

1.2 Feedback about these instructions

We make every effort to ensure that these instructions are as informative and as clear as possible. If you have any suggestions for improving the design or if some information is missing in the document, please send your suggestions to techdoc@turck.com.

2 Carrying out a firmware update with PACTware

Requirements

The PACTware FDT frame application, the DTM for the device and the latest firmware can be downloaded free of charge from www.turck.com.

- The module rack must be connected to the power supply.
- The screws of the power supply modules have been tightened or the locking cap has been locked in place.
- The gateway is plugged in and is connected to a PC via an Ethernet cable.
- PACTware 6.0 must be installed.
- The latest firmware file has been downloaded.

The device is operational automatically once the power supply is switched on.

Adding a gateway in PACTware

- ▶ Open PACTware.
- ▶ Create a new project.
- ▶ Double-click **BL Service Ethernet**.




Fig. 1: Adding a gateway in PACTware

Carrying out a firmware update

- ▶ Double-click **TCP:192.168.167.110**.
- ▶ Select the Ethernet interface.
- ▶ To select the gateway for the firmware update: Click the Search icon.




Fig. 2: Select the Ethernet interface

- ▶ In the **Busaddress management** window, select the firmware update icon with the green arrow.




Fig. 3: Firmware update icon

- ⇒ The window for selecting the firmware update opens.



NOTE

When updating to V.1.6.0.0, the current boot loader must be installed first.

- ▶ In the next step, select the boot loader file instead of the firmware update.

- ▶ Open the folder where the firmware update is saved and select the file.
- ▶ Click Open.




Fig. 4: Selecting the firmware update

The firmware update is carried out. A progress bar appears under **TCP:192.168.167.110** in the sidebar and above the PACTware logo. The firmware update may take up to five minutes.




Fig. 5: Firmware update in progress

If the firmware update is successful, the following message is displayed:




Fig. 6: Firmware update carried out successfully

Checking the firmware version

- ▶ In the **Busaddress management** window, click the search icon.
- ⇒ The **Version** column displays the current firmware version.




Fig. 7: Current firmware version in PACTware

Alternatively, the firmware version can also be checked in the web server. The device is factory set to IP address 192.168.1.254. To open the web server via a web browser, enter 192.168.1.254 in the address bar of the web browser. Navigate to **EXCOM GEN-3G** → **Info** → **Firmware revision** via the left-hand sidebar to display the current firmware version.

The screenshot shows the web interface for the EXCOM GEN-3G Gateway. On the left is a sidebar menu with options: Info (highlighted with a red box), Parameter, Diagnosis, Status, Control, Event log, Ex- / Import, Change Password, and Firmware. Below the menu are slot configurations: SLOT 1: DM80EX S, SLOT 2: DO40EX, SLOT 3: AIH40EX, SLOT 4: AOH40EX, SLOT 5: DF20EX F, SLOT 6: TI41EX, SLOT 7: EMPTY SLOT EX, and SLOT 8: EMPTY SLOT EX. The main content area is titled 'excom GEN-3G - Gateway - Info' and features a product image of the 'Multiprotocol-Interface for GEN'. Below the image is a 'Device' section with 'Station information' listed in a table:

Type	GEN-3G
Ident. no.	100004545
Firmware revision	1.6.0.0
Bootloader revision	10.0.1.0
Firmware revision (CPU 2)	1.6.0.0
Bootloader revision (CPU 2)	1.0.5.0
EtherNet/IP revision	2.7.55.0
PROFINET revision	1.7.27.0
Modbus/TCP revision	2.4.9.0
WEB revision	1.4.18.0
Software build number	1130

Fig. 8: Current firmware version in the web server

3 Turck subsidiaries — contact information

Germany	Hans Turck GmbH & Co. KG Witzlebenstraße 7, 45472 Mülheim an der Ruhr www.turck.de
Australia	Turck Australia Pty Ltd Building 4, 19-25 Duerdin Street, Notting Hill, 3168 Victoria www.turck.com.au
Belgium	TURCK MULTIPROX Lion d'Orweg 12, B-9300 Aalst www.multiprox.be
Brazil	Turck do Brasil Automação Ltda. Rua Anjo Custódio Nr. 42, Jardim Anália Franco, CEP 03358-040 São Paulo www.turck.com.br
China	Turck (Tianjin) Sensor Co. Ltd. 18,4th Xinghuazhi Road, Xiqing Economic Development Area, 300381 Tianjin www.turck.com.cn
France	TURCK BANNER S.A.S. 11 rue de Courtalin Bat C, Magny Le Hongre, F-77703 MARNE LA VALLEE Cedex 4 www.turckbanner.fr
Great Britain	TURCK BANNER LIMITED Blenheim House, Hurricane Way, GB-SS11 8YT Wickford, Essex www.turckbanner.co.uk
India	TURCK India Automation Pvt. Ltd. 401-403 Aurum Avenue, Survey. No 109 /4, Near Cummins Complex, Baner-Balewadi Link Rd., 411045 Pune - Maharashtra www.turck.co.in
Italy	TURCK BANNER S.R.L. Via San Domenico 5, IT-20008 Bareggio (MI) www.turckbanner.it
Japan	TURCK Japan Corporation Syuuhou Bldg. 6F, 2-13-12, Kanda-Sudacho, Chiyoda-ku, 101-0041 Tokyo www.turck.jp
Canada	Turck Canada Inc. 140 Duffield Drive, CDN-Markham, Ontario L6G 1B5 www.turck.ca
Korea	Turck Korea Co, Ltd. B-509 Gwangmyeong Technopark, 60 Haan-ro, Gwangmyeong-si, 14322 Gyeonggi-Do www.turck.kr
Malaysia	Turck Banner Malaysia Sdn Bhd Unit A-23A-08, Tower A, Pinnacle Petaling Jaya, Jalan Utara C, 46200 Petaling Jaya Selangor www.turckbanner.my

Mexico	Turck Comercial, S. de RL de CV Blvd. Campestre No. 100, Parque Industrial SERVER, C.P. 25350 Arteaga, Coahuila www.turck.com.mx
Netherlands	Turck B. V. Ruiterlaan 7, NL-8019 BN Zwolle www.turck.nl
Austria	Turck GmbH Graumanngasse 7/A5-1, A-1150 Wien www.turck.at
Poland	TURCK sp.z.o.o. Wroclawska 115, PL-45-836 Opole www.turck.pl
Romania	Turck Automation Romania SRL Str. Siriului nr. 6-8, Sector 1, RO-014354 Bucuresti www.turck.ro
Russian Federation	TURCK RUS OOO 2-nd Pryadilnaya Street, 1, 105037 Moscow www.turck.ru
Sweden	Turck Sweden Office Fabriksstråket 9, 433 76 Jonsered www.turck.se
Singapore	TURCK BANNER Singapore Pte. Ltd. 25 International Business Park, #04-75/77 (West Wing) German Centre, 609916 Singapore www.turckbanner.sg
South Africa	Turck Banner (Pty) Ltd Boeing Road East, Bedfordview, ZA-2007 Johannesburg www.turckbanner.co.za
Czech Republic	TURCK s.r.o. Na Brne 2065, CZ-500 06 Hradec Králové www.turck.cz
Turkey	Turck Otomasyon Ticaret Limited Sirketi Inönü mah. Kayisdagi c., Yesil Konak Evleri No: 178, A Blok D:4, 34755 Kadiköy/ Istanbul www.turck.com.tr
Hungary	TURCK Hungary kft. Árpád fejedelem útja 26-28., Óbuda Gate, 2. em., H-1023 Budapest www.turck.hu
USA	Turck Inc. 3000 Campus Drive, USA-MN 55441 Minneapolis www.turck.us

TURCK

Over 30 subsidiaries and over
60 representations worldwide!

100041346 | 2022/06



www.turck.com